

Переходники



4

№	НАИМЕНОВАНИЕ
1	F03-F03-H45
2	F03-F0304-H45
3	F0304-F05-H35
4	F05-F05-H45
5	F0405-F0507-H45
6	F07-F10-H40
7	F0507-F0710-H55
8	F10-F071012-HH70
9	F0710-F1012-H79
10	F0712-F1014-H90.5









ТАБЛИЦА РАЗМЕРОВ, мм

Модель	DD10-K11-55	DD11-K11-55	DD13-K14-55	DD16-K22-70	DD22-K27-70
K1	11	11	14	22	27
B	10	11	13	16	22
H	55	55	55	70	70

Модель	K09-K09-H35	K09-K09-H45	K11-K11-H35	K11-K11-H45	K14-K14-H40	K14-K14-H45	K17-K17-H40
K1	9	9	11	11	14	14	17
K2	9	9	11	11	14	14	17
D	20	20	25	25	30	30	30
H	35	45	35	45	40	45	40

Модель	K17-K17-H55	K22-K22-H55	K22-K22-H70	K22-K22-H79	K22-K22-H90	K27-K27-H90
K1	17	22	22	22	22	27
K2	17	22	22	22	22	27
D	35	45	35	45	55	55
H	55	55	70	79	90	90

ПНЕВМАТИЧЕСКИЕ ПОВОРОТНЫЕ ПРИВОДЫ